


7" ANGLE SANDER 7" ANGLE POLISHER

PNEUMATIC TOOLS

MODEL NO. SP0470



PARTS LIST

Gut Nr. Item No	Teil Nr. Part No.	Description	Bezeichnung
1	829001	Hose Adapter	Luftanschluss
2	829002	Valve Body	Ventilgehäuse
3	829003	Screw	Schraube
4	829004	Washer	Unterlagscheibe
5	829005	Lever	Drücker
6	829006	Lever Pin	Stift
8	829008	Valve Stem	Ventil Stift
9	829009	O-Ring	O-Ring
10	829010	Spring	Feder
11	829011	Air Regulator	Luftregler
12	829012	O-Ring	O-Ring
13	829013	O-Ring	O-Ring
14	829014	Valve Screw	Schraube
15	829015	Bearing Cap	Lagerkappe
16	829016	Retaining Ring	Seegerring
17	B608ZZ	Ball Bearing	Kugellager
18	829018	Rear Plate	Endstück Hinten
19	829019	Rotor Blade	Rotorblatt
20	829020	Rotor (Sander)	Rotor (Winkelschleifer)
20	830020	Rotor (Polisher)	Rotor (Winkelpolier)
21	829021	Pin	Stift
22	829022	Cylinder	Zylinder
23	829023	Front Plate	Endstück Vorne
24	B6201	Ball Bearing	Kugellager
25	829025	Pinion Gear (Sander)	Ritzel (Winkelschleifer)

Gut Nr. Item No	Teil Nr. Part No.	Description	Bezeichnung
25	830025	Pinion Gear (Polisher)	Ritzel (Winkelpolier)
26	829026	Motor Housing	Motorgehäuse
27	829027	Dead Handle	Griff
28	829028	Spacer	Distanzscheibe
29	829029	Retaining Ring	Seegerring
30	829030	Wave Washer	Beilagscheibe
31	829031	Bevel Gear (Sander)	Getrieberad (Winkelschleifer)
31	830031	Bevel Gear (Polisher)	Getrieberad (Winkelpolier)
32	829032	Key	Keil
33	829033	Gear Shaft	Getriebeschaft
34	829034	Exhaust Deflector	Luft Blech
35	829035	Screw	Schraube
36	829036	Housing Cap	Gehäuse Kappe
37	829037	Cap Screw	Schraube
38	B6203Z	Ball Bearing	Kugellager
39	829039	Retaining Ring	Seegerring
40	829040	Pad Nut	Mutter
41	829041	Gasket	Dichtung
42	829042	Gasket	Dichtung
43	829043	Pad	Scheiben
45	829045	Exhaust Muffler	Luftanschluss
46	829046	Plastic cover	Plastisch Deckel
47	829047	Disc Spanner	Schraubenschlüssel
48	829048	Stop Spanner	Stop Schraubenschlüssel
49	829049	Rubber	Gummi